

CELLULAR HANDS FREE ACCESSORIES



HANDS FREE ADAPTOR

Mfg.	Model	Part No.
ATT	6650	CEL-38MIC
NEXTEL	i280/i600/i390	COM-8100MIC
NEXTEL	i1000	COM-8615MIC
NOKIA	252	CEL-59MIC
NOKIA	918	CEL-46MIC
NOKIA	2100 SERIES	CEL-38MIC
NOKIA	8620/8290	CEL-91MIC
NOKIA	5100/6100 SERIES	CEL-57MIC
SONY	1920/2700	CEL-63MIC
QUALCOMM	1960	CEL-68MIC

PLUG IN HANDS FREE SPEAKER PHONE

Mfg.	Model	Part No.
ERICSSON	600 SERIES	CEL-49HF
ERICSSON	738/788	CEL-47HF
MOTOROLA	ELITE	CEL-5ELHF
MOTOROLA	FLIP	CEL-5HF
MOTOROLA	STARTAC	CEL-41HF
NOKIA	918	CEL-46HF
NOKIA	2100 SERIES	CEL-38HF
NOKIA	5100/6100SERIES	CEL-57HF
SAMSUNG	1000	CEL-55HF
SAMSUNG	3500	CEL-87HF
SONY	1920/2700	CEL-63HF

HANDS FREE CAR KIT

Mfg.	Model	Part No.
NEXTEL	i500/i700/i390	COM-8971 CARKT
NEXTEL	i1000	COM-8615CARKT

HANDS FREE ADAPTOR

Mfg.	Model	Part No.
AUDIOVOX	CDM3500	CEL-98THF
AUDIOVOX	CDM3300	CEL-98THF
ERICSSON	T-28	CEL-100THF
ERICSSON	200/200 SERIES	CEL-12THF
ERICSSON	600 SERIES	CEL-49THF
ERICSSON	738/788	CEL-47THF
MOTOROLA	STARTAC	CEL-41THF
MOTOROLA	VADER	CEL-102THF
NOKIA	918	CEL-46THF
NOKIA	3310/3390	CEL-105THF
NOKIA	5100/6100 SERIES	CEL-57THF
NOKIA	8260	CEL-91THF
NOKIA	8210	CEL-92THF
SAMSUNG	411	CEL-55THF
SAMSUNG	3500	CEL-87THF
SAMSUNG	620/6100	CEL-109THF

PERSONAL HANDS FREE

Mfg.	Model	Part No.
AUDIOVOX	CDM120	CEL-UNEB
AUDIOVOX	MXV440	CEL-UNEB
AUDIOVOX	PCX3600	CEL-UNEB
ERICSSON	600 SERIES	CEL-49EB
LUCKY GOLDSTAR	V111/110	CEL-UNEB
mitsubishi	T200	CEL-UNEB
MOTOROLA	STARTAC	CEL-UNEB
MOTOROLA	VADER	CEL-UNEB
MOTOROLA	SELECT/FLIP/M70	CEL-UNEB
MOTOROLA	TIMEPORT	CEL-UNEB
NEXTEL	i500/i700	COM-8971EB
NOKIA	918	CEL-46THF
NOKIA	5100/6100 SERIES	CEL-57EB
SAMSUNG	T100	CEL-UNEB
QUALCOMM	Q2035	CEL-UNEB

NOTE: ADD "P" TO PART NUMBER FOR RETAIL PACKAGING