

**CAM-322, CAM-322PAN PANASONIC: BP-80, BP-88**



BATTERY PROFILE

**CAM-322 12V, 2300MAH**  
**CAM-322PAN 12V, 2300MAH**

*(ORIGINAL PANASONIC BATTERY)*

**LEAD ACID**

LENGTH: 7 1/8" WIDTH: 2 3/8" HEIGHT: 7/8"


BATTERY CHARGER: **CCA-V1012**

BATTERY ELIMINATOR: **CCA-8500**



CONTACT CONFIGURATION

**CAM-350, CAM-350PAN PANASONIC: 2012D, BP-50**



BATTERY PROFILE

**CAM-350 12V, 2000MAH**  
**CAM-350PAN 12V, 2000MAH**

*(ORIGINAL PANASONIC BATTERY)*

**LEAD ACID**

LENGTH: 5 5/8" WIDTH: 2 1/2" HEIGHT: 7/8"

BATTERY CHARGER: **CCA-V1012**

BATTERY ELIMINATOR: **CCA-3500**



CONTACT CONFIGURATION

**CAM-408, CAM-416, CAM-428 JVC BN-V408**



BATTERY PROFILE

**CAM-408 7.2V, 850MAH**

LENGTH: 2-1/4" WIDTH: 1 7/16" HEIGHT: 3/4"

**CAM-416 7.2V, 1700MAH**

LENGTH: 2-1/4" WIDTH: 1 7/16" HEIGHT: 1-1/2"

**CAM-428 7.2V, 2400MAH**

LENGTH: 2-1/4" WIDTH: 1 7/16" HEIGHT: 2-1/8"

**LITHIUM ION**

BATTERY CHARGER: **CCA-UC2**

BATTERY ELIMINATOR: **N/A**

BATTERY ELIMINATOR: **CCA-UTC**



CONTACT CONFIGURATION