

# CORDLESS PHONE BATTERIES – 49 MHZ, 900 MHZ, 2.4 GHZ



**PART NO.: BATT-098**  
4.8V 600MAH *NI-CAD*  
UNIDEN BT-098



**PART NO.: BATT-14**  
3.6V 1500MAH *NI-MH*  
PANASONIC HHR-P505



**PART NO.: BATT-17**  
2.4V 1500MAH *NI-MH*  
PANASONIC TYPE 17



**PART NO.: BATT-21**  
2.4V 300MAH *NI-CAD*  
SONY BP-T21



**PART NO.: BATT-23**  
3.6V 600MAH *NI-CAD*  
VTECH 910 ADL SONY BP-T23



**PART NO.: BATT-24**  
3.6V 1000MAH *NI-CAD*  
SONY BP-T24 AND OTHERS



**PART NO.: BATT-31**  
3.6V 600MAH *NI-CAD*  
SONY BP-T31



**PART NO.: BATT-33**  
3.6V 720MAH *NI-CAD*  
G.E. BT-33 AND OTHERS



**PART NO.: BATT-35**  
3.6V 600MAH *NI-CAD*  
G.E. BT-35



**PART NO.: BATT-36**  
3.6V 600MAH *NI-CAD*  
G.E. BT-36



**PART NO.: BATT-38**  
3.6V 1000MAH *NI-CAD*  
SONY BP-T38



**PART NO.: BATT-50**  
2.4V 600MAH *NI-CAD*  
SONY BP-T50



**PART NO.: BATT-100**  
3.6V 600MAH *NI-CAD*  
SONY NP100



**PART NO.: BATT-242**  
3.6V 600MAH *NI-CAD*  
SIEMENS 240/242



**PART NO.: BATT-305**  
2.4V 300MAH *NI-CAD*  
PANASONIC P-P305